

## Assembly Instructions

**Thank you** for purchasing the by TACO Marine Adjustable Transom Rod Rack. Since 1959, we have taken great pride in offering the highest-quality products with excellent customer service. We stand behind our products 100 percent. Please visit our website [tacomarine.com](http://tacomarine.com) for more detailed information on a wide variety of products and to register your new accessory for warranty.

### Box Includes

1. On a flat surface, assemble mounting pads and rod holder assembly so that pads are flush to mounting service.
2. Position entire assembly against transom, ensuring the splines are fully inserted into the rod rack assembly. Mark holes on transom through holes in mounting pads.
3. Set assembly aside. Drill 1/4" holes through marked holes in transom - avoiding fuel lines, electrical harnesses, etc. during the process.

**IMPORTANT: There must be ample space to attach nuts and washers to back of bolts.**

4. Use 3M 5200 sealant or equivalent (not included) to coat bolts. Install one pad and spline assembly and fasten with nuts and bolts to transom.

**IMPORTANT: Position rod rack assembly at desired angle over spline when mounting.**

5. Insert other spline mount into unattached side of rod rack assembly, ensuring pad is flush to the transom. Coat bolts with sealant and fasten securely.

- TRANSOM ROD RACK

**Required\***  
**\*not included**

- ELECTRIC DRILL

- 1/4" DRILL BIT

- MARINE-GRADE SILICONE SEALANT 3M 5200

### WARNING:

This product can expose you to chemicals including Di (2-ethylhexyl) Phthalate (DEHP), which is known to the state of California to cause cancer, birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

